

Fitting Instructions

Brush seals



Length:.....

Contents include

Aluminium carrier
Brush
Fitting instructions

Tools required

Tape measure
Pencil or marker
Saw (power or hand)
Self adhesive tape

For further information about our products please visit our website

www.lorientgroup.com

t: +61 (02) 9907 6221
f: +61 (02) 9907 6152
e: admin@lorientau.com.au

Instructions

1. Remove from packaging and measure lengths against existing head and jambs.
2. Slide out brush strip from aluminium holder and using a fine tooth hacksaw, cut holder to required length removing burrs from cut ends.
3. Cut brush strip to suit using combination pliers, (which will automatically lock in bristles).
4. Before replacing brush strip, bend slightly and slide back into aluminium holder, (this will prevent the brush strip from sliding out of the holder).
5. Prior to fixing seal in place, ensure all surfaces are smooth and clean, (methylated spirit or alcohol is suitable, do not use oil based solvents).
6. Position seal and pencil mark fixing location.
7. Peel off backing paper and lightly position on premarked location. Press firmly into place along full length of strip.
8. Optional Fixing - Drill holes on aluminium holder and screw fix, (screws not supplied).

Please note: *Recommendations as to methods, use of materials and construction details are based on the experience and knowledge of Lorient and are given in good faith as a general guide and service to designers, contractors and manufacturers.*

Lorient reserves the right to make alterations or delete installation detail without prior notice.



Important:

Do not install these products to impede the opening or closing of the door. It is recommended to check the adjustment of the door seal periodically to ensure the door assembly closes and latches properly, whether or not equipped with a closing device.

Other Lorient products:

Acoustic, smoke & fire seals
Fire resistant glazing systems
Fire resistant door hardware
Air transfer grilles/ dampers