


Fitting instructions

Wipe seals

LAS 1011

Firtree® seal



Length:.....

Contents include

Elastomeric seal
Fitting instruction

Tools required

Tape measure
Pencil or marker
Router with 3mm cutter (Firtree® only)
Scissors, knife or snips

For further information about our products please visit our website

www.lorientgroup.com

t: +61 (02) 9905 0868
f: +61 (02) 9905 0883
e: admin@lorientau.com.au

Instructions

LAS 1011 Firtree® seal

1. Remove seal from packaging and mount in the door edge.
2. Groove the door or frame 3mm wide x 4mm deep.
3. Push fit the LAS 1011 product into the groove.



Please note: Recommendations as to methods, use of materials and construction details are based on the experience and knowledge of Lorient and are given in good faith as a general guide and service to designers, contractors and manufacturers.

Lorient reserves the right to make alterations or delete installation detail without prior notice.

Other Lorient products:

Acoustic, smoke & fire seals
Fire resistant glazing systems
Fire resistant door hardware
Air transfer grilles/ dampers



Lorient Pty Ltd
Unit 30, 9 Powells Road
Brookvale 2100
New South Wales
Australia

+61 (02) 9905 0868
www.lorientgroup.com

All rights reserved. No part of this fitting guide may be reproduced, stored in a retrieval system, or transmitted in any means, electronic, mechanical, photocopying, recording or otherwise without the written permission of Lorient Polyproducts Limited.
© Lorient Polyproducts Ltd 2018