



Fitting instructions

Batwing® seals



LAS 1212
Batwing®



LAS 1515
Batwing®

Tools required

Tape measure
Pencil or marker
Scissors

For further information about our products please visit our website

www.lorientgroup.com

t: +61 (02) 9905 0868
f: +61 (02) 9905 0883
e: admin@lorientau.com.au

Instructions

Please note: Batwing® needs to have a 3mm maximum gap between the door and the door stop to enable the door to close. Excessively tight gaps may dislodge the seal from its position and cause the door to bind.

It is essential to ensure that freshly painted surfaces are fully dry and cured before commencing installation.

1. Remove Batwing® from packaging and trim to length using scissors.
2. Peel adhesive from both legs of the Batwing® approx 100mm.
3. Mount in the top corner, using a jointing method as tight as possible to ensure continuity of seal.

Please note: Recommendations as to methods, use of materials and construction details are based on the experience and knowledge of Lorient and are given in good faith as a general guide and service to designers, contractors and manufacturers.

Lorient reserves the right to make alterations or delete installation detail without prior notice.

4. Run finger down centre of the profile pushing it into the centre of the reveal.
5. Pull adhesive backing strips off both legs a little at a time, progressively pushing Batwing® into place.

Important

The product will not adhere to surfaces where silicone sealant has been applied or where non-stick nano technology anti-graffiti paint has been used.

Other Lorient products:

Acoustic, smoke & fire seals
Fire resistant glazing systems
Fire resistant door hardware
Air transfer grilles/ dampers

