# SYSTEM XLAM 1


### **CROSS LAMINATED TIMBER WALL**

#### DESCRIPTION

- 1 Plasterboard fixed to wall and aperture:
  - 1 layer of 16mm or 2 layers of 13mm fire rated plasterboard (FRL 90 minutes)

∩R

- 2 layers of 16mm fire rated plasterboard (FRL 120 minutes)
- 2 XLam CLT panel. Thickness: 85mm to 315mm.
- 3 Angles fixed to damper casing with steel fasteners at 150mm centres or at least 2 per side.
- 4 0.6mm (min) Z275 galvanised steel angles to all four sides. Angles shall be continuous and at least 2 x the dimension of the gap between the damper casing and the wall.
- 5 Z275 galvanised steel casing min thickness 0.6mm.
- 6 Lorient LVH44 intumescent fire damper.
- 7 Casing terminates with breakaway joints as per AS1682.2.
- 8 Fire damper perimeter sealed with Lorient intumescent sealant.
- 9 Fire damper fixed to casing with 2 x steel screws.
- 10 Gap between damper and aperture filled with Lorient Intumescent sealant.



## LVH44 in steel casing penetrating a fire rated XLam CLT Wall

## FRL Up to -/120/60

# Fire Resistance in accordance with

AS1530.4 2014

# Approval Ref

CSIRO FCO 3300

#### Maximum size

Area not to exceed 0.2m<sup>2</sup>

### INSTALLATION INSTRUCTIONS

- ▶ Prepare the wall opening to accept the fire damper as per point 1.
- Mechanically fix angle brackets to one side of damper casing with steel screws as per point 3.
- Install casing into wall aperture and firestop the gap between the casing and wall with Lorient intumescent sealant.
- ▶ Fix angle brackets to reverse side with steel self drilling screws as per point 3.
- Ensure product identification labels are conspicuously positioned for easy identification.
- Ensure convenient access is provided to allow for AS1851 inspection and maintenance routines.

Note: Angles and fixings supplied by others.

